


### Rear panel vent

#### To remove

1. Remove the rear panel from the centre console by pulling it straight backwards.



#### To fit

1. Refit the rear panel to the centre console.

